



# 15 MINUTE CONCRETE

A high quality concrete ideally suited for the placement of posts.  
No need for mixing – just add water!  
Sets in minutes.

## PRODUCT DESCRIPTION

**STRONGCRETE 15 MINUTE** is an easy to use fast-setting concrete consisting of a special blend of cement, graded dry quality sand and aggregates and selected additives. Only water is required.

**STRONGCRETE 15 MINUTE** achieves a set in minutes and a 28 day strength of 20MPa.

**STRONGCRETE 15 MINUTE** is ideal for applications involving placement of posts – from erecting fences to securing clothes lines and mail boxes. Simply concrete in the post and carry on with the job!

**STRONGCRETE 15 MINUTE** is not recommended for structural concrete, please use **STRONGCRETE HI-STRENGTH 15 MINUTE CONCRETE** or **STRONGCRETE 36 MPa CONCRETE**.

## QUANTITIES

Please refer to our website [www.strongcrete.co.nz](http://www.strongcrete.co.nz) for our concrete calculator.

As a guide: For posts up to 1.8m in length, use one 25kg bag of **STRONGCRETE 15 MINUTE**. For larger posts use two bags. Generally the diameter of a post hole should be twice the diameter of the post. For extra strength use more **STRONGCRETE 15 MINUTE** or use **STRONGCRETE HI-STRENGTH 15 MINUTE**.

## WATER

A measured water supply is required.

## SAFETY

As with all cement materials, avoid eye contact, swallowing and excessive skin contact.

- Freshly mixed concrete or mortar may cause skin irritation including alkaline burning and dermatitis.
- Avoid contact with the skin by wearing suitable clothing and gloves.
- In the event of contact with skin or eyes, rinse thoroughly with water.
- If swallowed, drink 1-2 glasses of water.
- If irritation persists, seek medical attention.

## IMPORTANT

Do not mix – pour directly into hole

## MIXING INSTRUCTIONS

### 1. WET THE HOLE

Thoroughly wet the hole to compensate for any ground drainage which may soak up water required for the **STRONGCRETE 15 MINUTE**. NB: In sandy soils line the post hole with plastic to slow water loss.

### 2. PLACE

Place and position post in the hole.

### 3. ADD WATER

Pour 3 litres of water per bag of **STRONGCRETE 15 MINUTE** into the hole. When measuring allow for any ground water present.

### 4. ADD STRONGCRETE 15 MINUTE

Immediately pour one bag of **STRONGCRETE 15 MINUTE** evenly around the post – do not mix.

### 5. CHECK

Re-check the post's positioning and sparingly add water to any dry **STRONGCRETE 15 MINUTE** visible and level the surface straight away if necessary.

## NOTE:

1. If using more than one bag of **STRONGCRETE 15 MINUTE**, repeat steps 1-5. The layers of **STRONGCRETE 15 MINUTE** may be separated by a layer of compacted earth.
2. After a minimum of 15 minutes, the hole can be topped up with compacted earth and the superstructure can be drilled or nailed. If left for an hour the post will withstand more substantial pressure such as wire straining.

## STORAGE

Keep dry and store off the ground.

PROUDLY MANUFACTURED IN NEW ZEALAND BY STRONGCRETE LTD  
PO Box 109, Greenhithe, Auckland 0756  
Ph 0800 MYSTRONGCRETE (697876) | Order Fax 0800 379 329  
sales@strongcrete.co.nz | www.strongcrete.co.nz



FIORINI  
RAINSHIELD  
WWW.FIORINI.BIZ  
TEL +39 071 66061

